

**Gan Charger
GM3A
Instruction Manual**




Read the instruction manual thoroughly before use.

Keep the manual for future reference.

Using Your Product

1. Connect the charger to a wall outlet.
2. Connect your rechargeable devices to the USB/USB-C ports of the charger with the provided USB-C cable or another certified cable.



Specifications

Input : AC 100-240V, 50/60Hz, 1.5A (Max.)

Output : USB-C1/C2 : 5V/9V/12V/15V= 3A, 20V= 3.25A (65W Max.)

USB-A : 4.5V=5A, 5V= 4.5A, 9V= 3A, 12V= 2.5A, 20V
1.5A (30W Max.)

USB-C1 + USB-C2 : 45W + 18W (63W Max.)

USB-C1 + USB-A : 45W + 18W (63W Max.)

(USB-A/C2 : 5V= 3A or 9V= 2A or 12V= 1.5A)

USB-C2 + USB-A : 5V= 3A (15W Max.)

USB-C1 + USB-C2 + USB-A : 45W + 5V= 3A (60W Max.)

Total Output : 65.0W

Dimension : 67x42x31mm

Weight : 113g

Safety information

Please read below safety notes carefully before use to avoid any personal injury and property damage caused by improper use of the product. Any warranty claims or returns caused by misuses will not be accepted.


- Keep the product away from children and infirm persons.
- Keep the product away from heat sources, combustible gas, humidity and liquids.
- Do not attempt to repair, disassemble or destroy the product in any way.
- Keep the product away from metallic or conductive objects to avoid short-circuit.
- Do not operate a wet or otherwise damaged product.
- The product is only suitable for use at an altitude of 2000m or below

使用前请仔细阅读本使用说明手册。

请保留本手册以备将来参考。

产品的使用方法

- 1 将充电器连接到墙上电源插座
- 2 使用包装内提供的USB-C充电线或其他经认证的充电线，将充电器的USB-A或USB-C连接埠与你的充电设备相连接。



规格

输入 : AC 100-240V, 50/60Hz, 1.5A (最大)

输出 : USB-C1/C2 : 5V/9V/12V/15V = 3A, 20V = 3,25A (65W Max.)

USB-A : 4.5V = 5A, 5V = 4.5A, 9V = 3A, 12V = 2.5A, 20V
1.5A (30W Max.)

USB-C1 + USB-C2 : 45W + 18W (63W Max.)

USB-C1 + USB-A : 45W + 18W (63W Max.)

(USB-A/C2 : 5V = 3A或9V = 2A 或12V = 1.5A)

USB-C2 + USB-A : 5V = 3A (15W Max.)

USB-C1 + USB-C2 + USB-A : 45W + 5V = 3A (60W Max.)

总输出 : 65.0W

尺寸 : 67x42x31mm

重量 : 113g

安全提示

请仔细阅读以下安全提示以防因不正确使用本产品而引致的人身伤害及财产损失。本公司将不接受任何因不正确使用所造成的保养索赔或退货。

- 本产品应远离儿童及体弱者。
- 本产品应远离热源、可燃气体、潮湿处和液体。
- 请勿尝试以任何形式自行维修、拆开或毁坏本产品。
- 本产品应远离金属或导电物体以防止短路。
- 如本产品已受潮或损坏, 请勿使用。
- 产品仅适用于2000m海拔以下安全使用。

中国区客户支持

有限保修12个月

服务热线:400 133 5250